

ШУМОГАСИТЕЛИ

- Шумогасители предназначены для предотвращения шума и вибрации на выпускной линии компрессора
- Звуки, исходящие от поршневого компрессора, снижаются до минимального уровня за счет коллизии внутри камер, благодаря камерам с отверстиями.
- Они могут монтироваться в соответствии с любым направлением потока.
- При выборе шумогасителя достаточно ориентироваться на соответствие выпускной линии компрессора.
- Для устранения вибраций, которые могут стать причиной неисправной работы шумогасителя, необходимо закрепить вход и выход шумогасителя.
- У стандартных продуктов предусмотрено соединение ODS.
- Цвет [RAL] 5009

MUFFLERS

- Mufflers are designed to prevent noise and vibration in outlet line of compressor.
- Sounds resulting from piston compressors are decreased to minimum level by collision within chambers thank to chambers with holes.
- They can be mounted according to any direction of flow.
- When selecting a muffler it is enough to see suitability for compressor's outlet pipe.
- Muffler's inlet and outlet must be fixed in order to eliminate vibrations that may lead to low performance of the muffler.
- ODS connection is used in standard products.
- Color [RAL] 5009